

APPLICATION DIRECTIONS (HOUSEHOLD IRON)

1. Preheat iron to cotton setting (about 320-340 degrees). **NO STEAM!**
2. Place appliqué face up on a fabric. Press into place with your hand. If it is not in the desired position, lift and reposition. If any stones have shifted out of place, carefully put them back into place using tweezers.
3. Place a pressing cloth over appliqué carefully (do not disturb design), then place iron over the design area and apply steady pressure for 15 seconds (DO NOT MOVE IRON AROUND AS STONES MAY SHIFT) Place iron over another design area for another 15 seconds and repeat till entire design is pressed. (Do not overheat or glue will lose its adhesion).
4. Set aside and allow ironed on appliqué to cool.
5. For best care, wash garment inside out in cold delicate cycle & hanger dry.

